

CONNECT

Open the app and select the nearby TheStake identifier. Verify battery, storage, and signal strength.

- The dashboard mirrors the physical controls.
- Project data remains available offline after synchronization.

PROJECT SETUP

Enter the site, unit, operator, grid size, and project notes before setting the datum.

- Use clear institutional naming conventions.
- Confirm device time and project timezone.

CAPTURE

Select image, LiDAR, or both. Enter the depth for manual capture or set a timed interval.

- Depth captures should be consistent.
- Review images and point clouds after each critical level.

REPORTS

Generate a report or timelapse from the project log.

- Include the grid and corner-coordinate summary.
- Retain original records alongside exports.